



MOVI-C[®] Software License Upgrade

**Step-by-step instructions to upgrade a
drive's application level**



Contents

1	Preparation	3
1.1	Preparation of PC-software and drivers.....	3
1.2	Check the installed MOVISUITE® version and module package.....	3
1.3	Communication Interface	4
2	Connect to the inverter via MOVISUITE® and check application level.....	7
2.1	Start the MOVISUITE® software.....	7
2.2	Configure communication port.....	7
2.3	Scan the device.....	8
3	Update process	9
3.1	Check the activated application level of the drive.....	9
3.2	Order the software license to upgrade the application level.....	9
3.3	Access the license manager on the SEW-EURODRIVE website.....	10
3.4	Activate the license on the SEW-EURODRIVE website	11
3.5	Upgrade the application level in MOVISUITE.....	12
3.6	Change the application level of the device.....	13
3.7	Check the application level of the device	13



1 Preparation

1.1 Preparation of PC-software and drivers

Download and install the latest version of MOVISUITE®. At least version MOVISUITE® 2.10.52.0 is required for all available MOVIKIT® modules. You can download the most recent MOVISUITE software from the [SEW-EURODRIVE website](#).

The screenshot shows the 'Data & documents' section of the website, with the 'Software' tab selected. Below the navigation tabs, there is a search bar with a dropdown menu set to 'All products' and another dropdown menu set to 'MOVISUITE® V2.20'. A 'Find' button is located to the right of the search bar. Below the search bar, there is a red bar with the text 'Download selection as a ZIP file' and a 'Forward' button. Below this bar, there is a table with the following data:

	Designation	Size	Version
<input type="checkbox"/>	Latest: MOVISUITE® V2.20 Basic version (release date: 2021/01/28)	6.29 GB	2.20
<input type="checkbox"/>	Latest: MOVISUITE® V2.20 ModuleUpdatePackage 1 (release date: 26.02.2021)	4.96 GB	2.20

1.2 Check the installed MOVISUITE® version and module package

Click button .

Click button "Program information" to check the installed version and module package. It could take a short time until the module package appears.

The screenshot shows the MOVISUITE standard software interface. The top bar contains the MOVISUITE standard logo and several navigation icons: Start, Projects, Contact, Language, Settings, and Program information. The main area displays the MOVISUITE standard logo and the following information:

Version V2.20 (2.20.15.0) —
Module package 2.20.15.0



1.3 Communication Interface

To communicate to the devices e.g. an USB-CAN Adapter USM21A needs to be used.
The driver for USM21A adapter is already installed with MOVISUITE®.


Adapter	
SEW part number	28231449
Included items	USM21A communication adapter USB connection cable 1.5m, USB-A -> USB-B, 08186804 RJ10 connection cable 3.0m, RJ10 -> RJ10, 08146993

Decentralized Drives: Connection to X31


Adapter	<p style="text-align: right;">9007224818777355</p>
	<p>[1] USB 2.0 connection cable (commercial, included in the delivery of USM21A)</p> <p>[2] Interface adapter USM21A</p> <p>[3] RJ10/RJ10 connection cable (included in the delivery of the USM21A interface adapter)</p>
SEW part number	28231449
Included items	USM21A interface adapter The following connection cables are included in the delivery: <ul style="list-style-type: none"> • USB 2.0 connection cable <ul style="list-style-type: none"> – USB type A/USB type B, – Length: 1.5 m • RJ10/RJ10 connection cable <ul style="list-style-type: none"> For connection to the engineering interface X31 – With 2 RJ10 plug connectors – Length: 3 m



Decentralized Drives: Connection to X4142

<p>Adapter</p>	 <p>[1] USB 2.0 connection cable (commercial, included in the delivery of USM21A)</p> <p>[2] Interface adapter USM21A</p> <p>[3] Connection cable RJ10/M12</p> <p>9007224819186315</p>
<p>SEW part numbers</p>	<p>28231449 28139038 28258185</p>
<p>Included items</p>	<p>Connection cable RJ10/M12 For connection to the engineering interface X4142</p> <ul style="list-style-type: none"> • With RJ10 plug connector • With M12 plug connector, 5-pin, male, B-coded • Length: 3 m <p>Retrofit set M12 engineering interface X4141</p>

Centralized Drive / Cabinet Inverter: Connection to X32

<p>Adapter</p>	
<p>SEW part numbers</p>	<p>[1]/[3] 28231449 [2] 18123864</p>
<p>Included items</p>	<p>[2] Connection cable RJ10/D-Sub plug connector For connection to the engineering interface X32</p> <ul style="list-style-type: none"> • With RJ10 plug connector



	<ul style="list-style-type: none"> • With D-Sub plug connector
--	---

Centralized Drive / Cabinet Inverter: Connection to the CBG keypad

Adapter	
SEW part numbers	
Included items	<p>[2] Connection cable USB A-Mini-B For connection to the CBG11A/CBG21A/CBG22A</p>

Other connection possibilities such as via MOVI-C CONTROLLER, EtherCAT or engineering via fieldbus can be used as well. Additional hardware could be required.

The used inverter or decentralized drive needs to be powered by 380-500V mains voltage or 24 VDC auxiliary power.




2 Connect to the inverter via MOVISUITE® and check application level

2.1 Start the MOVISUITE® software



2.2 Configure communication port


Please make sure that the communication adapter is connected to an USB port of the PC **BEFORE** MOVISUITE® is started.



- (1) Click button „Start“ in the toolbar.
- (2) Click button “From network scan”.



2.3 Scan the device




In this example, the connection between the device and the PC is set up with the USM adapter. This also works with other connection types.


- (1) Select the communication “USB”.
- (2) Select the USB adapter. If you can't see USM21A as a connected USB adapter please check the connection of the USM21A to the SEW device and the connection of the USM21A to your PC.
- (3) Select SCAN.

Click button **Apply and start scan** on the bottom of the screen.

If the network scan was successful, a similar information pops up:




Click button “Apply”.



Click button “Yes, load device data”.

3 Update process

3.1 Check the activated application level of the drive



To check the activated application level, please check index 8438.2 in the permission settings .

Available application levels:

- 0: MOVIKIT® Velocity Drive
- 1: MOVIKIT® from application level 0
 MOVIKIT® Positioning Drive
 MOVIKIT® RapidCreepPositioning Drive
- 2: MOVIKIT® from application level 1
 MOVIKIT® customized

3.2 Order the software license to upgrade the application level

Depending on the requirements of your application, choose the new application level.

Order the application level upgrade from your regular sales contact – the same you ordered the device from.

The order acknowledgement will show a license key (sample marked in yellow) which will be needed to upgrade the application level of your device.



SEW-EURODRIVE---Driving the world					
Order acknowledgement				SEW EURODRIVE	
Order-No.: 0122		Date:		Page 2 / 2	
Pos.	Quantity	Part No.	Delivery date	price/pc	total price

The license keys are listed at the end of this document.

Total value excluding VAT EUR -----

Do you require additional information regarding your order?
The transaction overview offers you a compact overview of all your current orders after initial activation:
https://www.sew-eurodrive.de/os/c/main.do?viewset=OVERVIEW&type=order&language=EN_US&utm_source=output
It also contains CAD data, documentations, or technical product data for the ordered products.
In addition, you can create a documentation package for several products.


License keys

position 100:

Quantity application level 1: 2
VPYEG- 2KW9X-

3.3 Access the license manager on the SEW-EURODRIVE website

Open the license manager on the SEW website: [Online Support | SEW-EURODRIVE \(seweurodrive.com\)](https://www.seweurodrive.com/Online_Support).



- (1) Click "Online Support".
- (2) Click "Startup & maintenance".
- (3) Click "Check & activate software licenses".



3.4 Activate the license on the SEW-EURODRIVE website

Software licenses

Activate Request

Input

Activate software licenses
Enter the hardware ID of the SDI/FAST card, the PC, or the inverter system where the software is to be activated, and a license key.

1 Hardware ID


2 License key

3 Please note that a license can be activated only once. This process cannot be undone.


Activate license

(1) Add the serial number of the affected inverter / drive / electronic cover. You will find it:

- On the nameplate (inverter / drive / electronic cover) OR



- In index 8304.1 (MOVISUITE – device needs to be connected to a PC)




- (2) Add the license key from the order acknowledgement (see step 3.2).
- (3) Select the red button “Activate license”.

Please note that each license can be activated only once! After you activated the license for one component/ serial number, it cannot be unlinked.

- (4) You will get an activation key which is unique for the previously selected SEW device. This activation key is needed for the activation in MOVISUITE.

3.5 Upgrade the application level in MOVISUITE

- (1) Enter the activation key in index 8438.11 “Application level – activation key”.






3.6 Change the application level of the device

You are now able to change the setting of the application level e.g. from “Velocity Drive” to “Positioning Drive”.

Right click in the lower half-circle of the device in MOVISUITE and delete the existing software module.

- (1) Select “Add software module”.
- (2) Choose the new required MOVIKIT.



3.7 Check the application level of the device

You can check the activated level again. The newly selected application level – in this case “1” is shown now.

